



INSTRUCTIONS FOR USE

1. PRESS THE POWER BUTTON 5 TIMES TO TURN ON/OFF
2. PRESS THE POWER BUTTON 3 TIMES TO CYCLE THROUGH THE 4 COLOR-CODED VOLTAGE SETTINGS [YELLOW 2.6V, GREEN 3.0V, RED 3.6V, BLUE 4.2V]
3. PRESS THE POWER BUTTON 2 TIMES TO ACTIVATE 10 SECOND SESH MODE
4. REMOVE MOUTHPIECE, LOAD DESIRED MATERIAL INTO HEATING CHAMBER.
5. SCREW MOUTHPIECE BACK ON
6. PRESS AND HOLD POWER BUTTON
7. INHALE AND ENJOY

WARNING: DO NOT OVERFILL THE CHAMBER. IT NEEDS AIRFLOW TO BREATHE. ONLY APPLY .1 GRAM DURING EACH SESSION OR YOU WILL FLOOD THE CHAMBER. REMOVE MOUTHPIECE FILTER IF FILTER GETS CLOGGED.

GET PRODUCT SUPPORT:

Customer Service Phone Number: 855-526-3904
Customer Service Email: support@kandypens.com

*FOR AROMATHERAPY PURPOSES ONLY. THIS PRODUCT IS NOT A SMOKING DEVICE FOR TOBACCO. MUST BE AT LEAST 21 YEARS OF AGE OR OLDER TO PURCHASE AND USE.



INSTRUCTIONS FOR USE

1. PRESS THE POWER BUTTON 5 TIMES TO TURN ON/OFF
2. PRESS THE POWER BUTTON 3 TIMES TO CYCLE THROUGH THE 4 COLOR-CODED VOLTAGE SETTINGS [YELLOW 2.6V, GREEN 3.0V, RED 3.6V, BLUE 4.2V]
3. PRESS THE POWER BUTTON 2 TIMES TO ACTIVATE 10 SECOND SESH MODE
4. REMOVE MOUTHPIECE, LOAD DESIRED MATERIAL INTO HEATING CHAMBER.
5. SCREW MOUTHPIECE BACK ON
6. PRESS AND HOLD POWER BUTTON
7. INHALE AND ENJOY

WARNING: DO NOT OVERFILL THE CHAMBER. IT NEEDS AIRFLOW TO BREATHE. ONLY APPLY .1 GRAM DURING EACH SESSION OR YOU WILL FLOOD THE CHAMBER. REMOVE MOUTHPIECE FILTER IF FILTER GETS CLOGGED.

GET PRODUCT SUPPORT:

Customer Service Phone Number: 855-526-3904
Customer Service Email: support@kandypens.com

*FOR AROMATHERAPY PURPOSES ONLY. THIS PRODUCT IS NOT A SMOKING DEVICE FOR TOBACCO. MUST BE AT LEAST 21 YEARS OF AGE OR OLDER TO PURCHASE AND USE.