



SESSION

INSTRUCTIONS FOR USE

1. PRESS THE POWER BUTTON 5 TIMES TO TURN ON/OFF
2. PRESS THE POWER BUTTON 3 TIMES TO CYCLE THROUGH THE 4 COLOR-CODED VOLTAGE SETTINGS [YELLOW 2.8V, GREEN 3.2V, RED 3.6V, BLUE 4.0V]
3. REMOVE MAGNETIC CAP, LOAD DESIRED MATERIAL INTO HEATING CHAMBER, PUT MAGNETIC CAP BACK ON
4. ATTACH SESSION TO GLASS BUBBLER OF YOUR CHOICE OR ATTACH GLASS MOUTHPIECE TO TOP OF ATOMIZER
5. PRESS THE POWER BUTTON 2 TIMES TO ACTIVATE SESH MODE
6. OR PRESS AND HOLD POWER BUTTON TO ACTIVATE ATOMIZER
7. INHALE AND ENJOY

WARNING: DO NOT OVERFILL CHAMBER, IT NEEDS AIRFLOW TO BREATHE. ONLY APPLY .1 GRAM DURING EACH SESSION OR YOU WILL FLOOD THE CHAMBER.

GET PRODUCT SUPPORT:

Customer Service Phone Number : 855-526-3904
Customer Service Email: support@kandypens.com

*FOR AROMATHERAPY PURPOSES ONLY. THIS PRODUCT IS NOT A SMOKING DEVICE FOR TOBACCO. MUST BE AT LEAST 21 YEARS OF AGE OR OLDER TO PURCHASE AND USE.



SESSION

INSTRUCTIONS FOR USE

1. PRESS THE POWER BUTTON 5 TIMES TO TURN ON/OFF
2. PRESS THE POWER BUTTON 3 TIMES TO CYCLE THROUGH THE 4 COLOR-CODED VOLTAGE SETTINGS [YELLOW 2.8V, GREEN 3.2V, RED 3.6V, BLUE 4.0V]
3. REMOVE MAGNETIC CAP, LOAD DESIRED MATERIAL INTO HEATING CHAMBER, PUT MAGNETIC CAP BACK ON
4. ATTACH SESSION TO GLASS BUBBLER OF YOUR CHOICE OR ATTACH GLASS MOUTHPIECE TO TOP OF ATOMIZER
5. PRESS THE POWER BUTTON 2 TIMES TO ACTIVATE SESH MODE
6. OR PRESS AND HOLD POWER BUTTON TO ACTIVATE ATOMIZER
7. INHALE AND ENJOY

WARNING: DO NOT OVERFILL CHAMBER, IT NEEDS AIRFLOW TO BREATHE. ONLY APPLY .1 GRAM DURING EACH SESSION OR YOU WILL FLOOD THE CHAMBER.

GET PRODUCT SUPPORT:

Customer Service Phone Number : 855-526-3904
Customer Service Email: support@kandypens.com

*FOR AROMATHERAPY PURPOSES ONLY. THIS PRODUCT IS NOT A SMOKING DEVICE FOR TOBACCO. MUST BE AT LEAST 21 YEARS OF AGE OR OLDER TO PURCHASE AND USE.